




EHM. Expansionador manual para anclaje hembra



> INSTALACIÓN



Referencia	Medida	d1 mm	d2 mm	L1 mm
EHM06	M6	5,0	7,5	14,8
EHM08	M8	6,6	9,5	18,0
EHM10	M10	8,3	11,5	23,0
EHM12	M12	10,2	14,5	28,0
EHM16	M16	13,5	19,5	33,0
EHM20	M20	16,8	24,5	47,0